

# SIMPLE GLOW

## Solar Lighting Made Easy

### Hanging Solar Light - Instructions/Warranty (Patent Pending)

Included: mounting hardware, rechargeable AA batteries pre-assembled, and instructions/warranty.

### Mounting Instructions

Screw grooved end of wall bracket into bottom of light. (See Fig. 1.) With screws provided, hang the wall hanging bracket flush to your desired flat surface.

### Replacing Batteries - **CAUTION: Failure to follow replacement procedures described below may damage the product.**

Lift the top off the light with your hands by placing your fingers under the rubber gasket on top and pulling upwards. For best results keep turning one inch at a time until the lid comes off. If needed, a flat-head screw driver may be used instead of your hands in the same fashion by turning an inch at a time all around the light. Careful not to rip the rubber with the screw driver as this may result in leakage into the solar panel.

Once the top is off, remove the plastic strip over the battery by placing the tip of a flat head screwdriver under the strip opposite the bulb and carefully lift up not to damage the light bulb. (See figure2.) This will dislodge the security strip. Replace the AA rechargeable battery.

Re-attach the plastic security strip by attaching the end opposite of the bulb first and then sliding the strip over the battery until it snaps into place. (See figure3.)

Securely replace the top. Make sure the top is snugly on for a proper seal. This will protect the control panel & batteries from the elements.

**Troubleshooting:** If the light doesn't work please check that the battery connection is secure. For dim lights or lights with short run times, you may need to replace the battery. The battery can be replaced with rechargeable AA batteries following the instructions above.

### Simple Glow Limited Warranty

Simple Glow Product Limited Warranty. Simple Glow warrants that your Simple Glow product be free from defects in workmanship and material for a period of 90 days, beginning from the date of purchase. Except where applicable by law, this warranty is non-transferrable and is limited to the original purchaser. This warranty gives specific, legal rights, and you may also have other rights, which vary from state to state. This warranty supersedes all prior warranties. Simple Glow agrees to correct such defects without charge or at our option replace with comparable or superior model provided the product is returned to the retailer or such other place as Simple Glow may direct. To obtain warranty service, you must present a copy of the receipt as proof of purchase. All costs of removing and reinstalling the product are your responsibility. This warranty does not cover damage to any part such as by accident or misuse or improper installation or by affixing any accessories. There is no other warranty. The retailer hereby disclaims any and all warranties, including but not limited to, those of merchantability and fitness for a particular purpose to the extent permitted by law. The duration of any implied warranty, which cannot be disclaimed, is limited to the time period as specified. Some states do not allow limitation on how long an implied warranty lasts, so the above limitation may not apply to you. Neither the retailer nor Simple Glow shall be liable for incidental, consequential or special damages arising out of or in connection with the product use or performance except as may otherwise be accorded by law. Some states do not allow the exclusion of the incidental or consequential damage, so the above exclusion or limitation may not apply to you.

Fig. 1




Fig. 2 (control panel)




Fig. 3 (control panel)

